

Tylosin (TYL) ELISA Kit

Technical Manual (ELISA)



Scan for more info.

Shenzhen Finder Biotech Co.,Ltd.

Web: www.szfinder.com

Tel: +86 0755 23499025 Email: techsupport@szfinder.com Add: Building B12,Life Science Industrial Park, KuiyongSubdistrict,

Dapeng New Area, Shenzhen, China

1 Principle and Application |-

This kit adopts the method of indirect competitive enzyme-linked immunoassay (ELISA) to detect Tylosin (TYL) in the sample such as poultry tissue, honey. The kit is composed of Microtiter Plate coated with coupled antigens, HRP conjugate, antibodies, standards and other supporting reagents. During the detection, with adding standards or samples, the TYL in the samples will compete with the coupled antigens to combine with anti-TYL antibodies. After adding HRP conjugate, take coloration with TMB substrates. Absorbance value of the samples is a negative correlation with TYL content. Lastly, by comparing the obtained absorbance values with the standard curve, we can calculate the TYL content in the sample.

2 Technique Data |-

2.1 Kit Sensitivity: 0.5ppb (ng/mL)

2.2 Reactive Mode: 25°C, 30min \sim 30min \sim 15min

2.3 Detection Limits:

| Sample | Detection Limits |
|----------------|-------------------------|
| Poultry tissue | 1ppb |
| Honey | 0.5ppb |
| Eggs, milk | 25ppb |

2.4 Cross-reaction Rate:

| Tylosin 100% | 6 |
|------------------------------------|---|
| Erythromycin | |
| Other macrocyclic lactone drugs<1% | 0 |

2.5 Sample Recovery Rate:

| Sample | Recovery rate |
|-------------------|---------------|
| Tissue | 85±10% |
| Eggs, honey, milk | 85±15% |

3 Composition of the Kit I-

| Reagent | Specification |
|---|------------------|
| Microtiter Plate | 8wells× 12strips |
| Standard: 0ppb, 0.5ppb, 1.5ppb, 4.5ppb, | 1.0mL each |
| 13.5ppb, 40.5ppb | None adon |
| Antibody solution (blue cap) | 1×5.5mL |
| HRP conjugate (red cap) | 1×11mL |
| Substrate Reagent A (white cap) | 1×6mL |
| Substrate Reagent B (black cap) | 1×6mL |
| Stop Solution (yellow cap) | 1×6mL |
| Concentrated Wash Buffer (20×)(white cap) | 1×40mL |
| Concentrated Reconstitution Buffer(2×) | 1×50ml |
| (yellow cap) | 1×50IIIL |
| Instruction | 1 |
| Adhesive Membrane | 1 |
| Sealed bag | 1 |

4 Materials Required but Not Supplied |--

- **4.1 Equipment:** microplate reader, printer, grinder (for homogenizing solid samples), nitrogen evaporator, vortex mixer (for shake and mix), centrifuge, graduated transfer pipette, and balance with a division value of 0.01 g, constant temperature device(25°C);
- **4.2 Micropipette:** single-channel (20-200μL and 100-1000μL), and multi-channel 300μL;
- **4.3 Reagents:** Sodium hydroxide, Methanol, Concentrated hydrochloric acid, Acetonitrile, Trichloromethane, n-Hexane.

5 Experimental preparation 1-

Restore all reagents and samples to room temperature (adjust to around 25°C) for more than 30 min before use. This is a crucial step to ensure there is no precipitation in the reagents.

5.1 Notice Before Sample Processing:

Please note that the labware must be clean. Use disposable pipette tips to avoid contamination of interference results.

5.2 Solution preparation:

Solution 1: 0.1 M NaOH Solution

Dissolve 0.4g of sodium hydroxide in deionized water to a final volume of 100ml.

Solution 2: 0.01 M NaOH Solution

Dissolve 0.4g of sodium hydroxide in deionized water to a final volume of 11.

Solution 3: 0.1 M HCl Solution

Dissolve 8.6mL of concentrated hydrochloric acid in deionized water and make up to a final volume of 1L.

Solution 4: Sample Extraction Solution

Take 84mL of acetonitrile, add 16mL of 0.1M HCI



Solution and mix well, then add 18mL of methanol and mix thoroughly.

Solution 5: Reconstitution Buffer

Dilute the Concentrated Reconstitution Buffer $(2\times)$ 2 times with deionized water (Reconstitution Buffer $(2\times)$: deionized water=1:1) for redissolving the sample. The solution can be stored at 4 °C for one month.

Solution 6: Working Wash Buffer

Dilute the concentrated wash buffer (20×) by a factor of 20 (Concentrated wash buffer/Deionized water= 1: 19).

5.3 Sample pretreatment steps:

5.3.1 Poultry tissue treatment.

- 1) Weigh $2g \pm 0.05g$ of homogeneous sample into a 50mL centrifuge tube. Add 8mL of Sample Extraction Solution (Solution 4), shake for 5 minutes, and centrifuge at 4000rpm for 10 minutes at room temperature.
- 2) Take 2mL of the supernatant, add 1mL of 0.1 M NaOH Solution (Solution 1), mix, then add 3mL of Trichloromethane, shake for 5 minutes, and centrifuge at 4000rpm for 10 minutes at room temperature.
- 3) Remove the upper layer, take 1.5mL of the lower layer liquid, and evaporate under nitrogen or air at 50-60°C in a clean glass test tube.
- 4) Dissolve the dried residue in 0.5mL of Reconstitution Buffer (Solution 5) and mix for 30 seconds.
- 5) Take 50µL for analysis.

Dilution times of the sample:2 Detection limits: 1ppb 5.3.2 Honey treatment.

- 1) Weigh 1g ± 0.05g of the sample into a 50mL centrifuge tube. Add 2mL of deionized water and shake for 2 minutes to dissolve it.
- 2) Add 10mL of trichloromethane, shake for 5 minutes,

and centrifuge at 4000rpm for 10 minutes at room temperature.

- 3) Remove the upper layer, take 5mL of the lower layer liquid, and evaporate under nitrogen or air at 50-60° C in a clean glass test tube.
- 4) Dissolve the dried residue in 0.5mL of Reconstitution Buffer (Solution 5) and mix for 30 seconds.
- 5) Take 50µL for analysis.

Dilution times of the sample:1 Detection limits: 0.5ppb 5.3.3 Egg treatment.

- 1) Break the eggshell, mix the egg white and yolk thoroughly, weigh 1g \pm 0.05g into a 15mL centrifuge tube. Add 4mL of 0.01 M NaOH Solution (Solution 2), shake for 2 minutes, and centrifuge at 4000rpm for 10 minutes at room temperature.
- 2) Take 2mL of the upper layer liquid into a 15mL centrifuge tube, add 4mL of n-hexane, shake for 2 minutes, and centrifuge at 4000rpm for 10 minutes at room temperature.
- 3) Remove the upper layer liquid, carefully passing through the gel-like substance in the middle layer, and take 0.1mL of the lower clear liquid into a 1.5mL centrifuge tube. Add 0.9mL of Reconstitution Buffer (Solution 5), shake well for 30 seconds, and take $50\mu L$ for analysis.

Dilution times of the sample:50 Detection limits: 25ppb 5.3.4 Milk treatment.

- 1) Take 0.5mL of milk into a 15mL centrifuge tube. Add 2mL of 0.01 M NaOH Solution (Solution 2), shake for 2 minutes, and centrifuge at 4000rpm for 10 minutes at room temperature.
- 2) Take 1mL of the upper layer liquid into a 15mL centrifuge tube, add 2mL of n-hexane, shake for 2 minutes, and centrifuge at 4000rpm for 10 minutes at room temperature.
- 3) Remove the upper layer liquid, carefully passing through the gel-like substance in the middle layer, and take 0.1mL of the lower clear liquid into a 1.5mL centrifuge tube. Add

0.9mL of Reconstitution Buffer (Solution 5), shake well for 30 seconds, and take 50µL for analysis.

Dilution times of the sample:50 Detection limits: 25ppb

6 ELISA procedure I-

Place all reagents and samples to room temperature (adjust to around 25°C) for 30min. Gently shake the reagent bottles before use.

Take out the frame of the microplate along with the required number of wells. Then place the unused microplate wells into the sealed bag with the desiccant provided. Store the remaining kit in the refrigerator at 2-8°C.

Step 1: Number: Number the wells in sequence corresponding to the samples and standard, make 2-well parallel trials for each sample and standard, and record their locations.

Step 2: Sample Incubation: Add $50\mu L$ of standard or sample into each numbered well, then add $50\mu L$ of antibody solution into each well. Finally, cover the Microtiter Plate with the adhesive membrane, shake gently by hand (or use a microplate shaker) for 5s and incubate for 30 min at 25°C in the dark.

Step 3: Washing: Uncover the adhesive membrane carefully, remove the liquid, pipette 350μ L of Working Wash Buffer (Solution 6) to every well, let stand for 30 seconds then drain, repeat 5 times. Invert the plate and tap it against a thick absorbent paper (or lint-free cloth), with a soft towel placed underneath. (Bubbles that are not removed after tapping dry can be punctured with a clean pipette tip).

Step 4: Enzyme Incubation: Add 100μ L of HRP conjugate into each well. Then cover the Microtiter Plate with the adhesive membrane, incubate for 30 min at 25°C in the dark.



Step 5: Washing: Same as step 3.

Step 6: Color: Add $50\mu L$ of Substrate Reagent A to each well. Then add $50\mu L$ of Substrate Reagent B per well. Shake gently by hand (or use a microplate shaker) for 5s, and allow to react for 15min at 25°C in the dark. (The reaction can be extended appropriately if the blue color is too pale.)

Step 7: Stop the reaction: Pipette $50\mu L$ of Stop Solution to each well, and shake gently by hand (or use a microplate shaker). The reaction would be stopped.

Step 8: Calculate: Determine the Optical Density (OD value; absorbance value) at 450nm (Reference wavelength 630nm) with a microplate reader. Finish this step within 10min after stop the reaction.

7 Interpretation of result |-

7.1 Calculate the percentage of absorbance value

Percentage of absorbance value(%)= $\frac{A}{A\Omega}$ ×100%

A—the average OD value of the sample or standard;

A0—the average OD value of the Oppb standard.

It is used to calculate the percentage absorbance of a standard or sample.

7.2 Draw the standard curve and calculate

Take absorbance percentage(A/A0) of standards as Y-axis and the corresponding log of standards concentration (ppb) as X-axis.

Draw the standard semi-log curves with X-axis and Y-axis.

Take absorbance percentage of samples substitute into standard curve, then can get the corresponding concentration from standard curve. Last, the resulting concentration values multiplied by the corresponding dilution times is the actual concentration of TYL of samples.

If professional analysis software of the kit is used for calculation, it is more convenient for accurate and rapid analysis of a large number of samples.

8 Attention |-

- 8.1 Before test, the reagents and samples should be balanced to room temperature (25°C). If below 25°C, it will lead to all the standard OD value on the low side.
- 8.2 In the washing process, dry wells may result in non-linear standard curves and undesirable reproducibility. Therefore, proceed to the next step immediately after washing.
- 8.3 Please mix the contents within the wells uniformly and wash the plate thoroughly. The reproducibility is largely determined by consistency of washing step.
- 8.4 During the incubation, cover microplates with adhesive membrane to avoid light.
- 8.5 Do not use kits that are overdue. Do not mix reagents with those from other lots.
- 8.6 Substrate Reagent A/B is colorless. If not, please discard.
- 8.7 If absorbance value of 0ppb is below 0.5 (A450nm<
- $0.5\,$), it means that the reagent may be metamorphic.
- 8.8 Stop solution is corrosives, please avoid contact with skin.
- 8.9 As the OD values of the standard curve may vary according to the conditions of actual assay performance (e.g. operator, pipetting technique, washing technique or temperature effects), the operator should establish a standard curve for each test.
- 8.10 For the mentioned sample, fast and efficient extraction methods are included in the kit description. Please consult technical support for the applicability if other sample need to be tested.

8.11 The kit is used for rapid screening of actual samples. If the test result is positive, the instrument method such as HPLC, LC/MS can be used for quantitative confirmation.

9 Storage conditions |

The kit shall be stored at 2-8 °C. Avoid freezing.

Shelf Life: 12 months. The date of manufacture is presented in the label of the box.